

## OPTICAL TRANSCEIVERS

光模块

Quick Start Guide **V2.1**

快速操作指南

# 1



**Caution against moisture.**

注意防潮



**Do not disassemble or modify.**

请勿拆卸或改装



**Please wear antistatic gloves.**

请戴防静电手套



**Never look into fiber ports.**


切勿直视光纤端口




**The transceiver can only be installed or replaced by qualified personnel.**

光模块由专业人员安装或更换

# 2





- 25G SFP28
- 10G SFP+




1G SFP

- 100G QSFP28
- 40G QSFP+



- 10G-T SFP+
- 1G-T SFP


# 3



**NOTE:** Take out the dust cap


注意：取出防尘帽

# 4




**NOTE:** Line up the module with the port and slide it gently into the port until the lock is fully seated.

注意：安装时将模块与端口对齐，然后将其轻轻滑入端口，直到锁完全到位。



**NOTE:** If remove the module, pull the ring outward.


注意：如需取出模块时，拉环向外拉动。



LC Cables Installation


LC光纤跳线安装

# 5




**NOTE:** When inserting into a device, please make sure the module matches the device bayonet properly. Do not push in or pull out the module with force.

注意：插入设备时，请确保模块与设备卡口正确匹配，请勿强行推入或拉出模块。



**NOTE:** If remove the module, pull the ring outward.

注意：如需取出模块时，拉环向外拉动。



MPO/ MTP Cables Installation

MPO/ MTP 跳线安装